**PLDT**
HOME
TELPAD

# MT7 Quick Guide

Before We Get Started

Register Your device

We strongly suggest that you register your device following the directions provided with the product. This will allow us to notify you when the latest firmware updates are available.

1. Microphone(tablet)
2. USB Port
3. Earphone Jack
4. IR1(transmit)
5. Front Camera
6. IR2(transmit and receive)
7. Volume Down Button
8. Volume UP Button
9. Power Button
10. Tablet Receiver
11. Proximity sensor
12. Light sensor
13. SIM card slot
14. Rear Camera
15. Rear Camera Flash
16. IR3(transmit)
17. Speakers(Tablet)
18. Micro SD Card Slot
19. Dock Connection Interface

20. Telephone Receiver/Handset
21. Speaker(Phone Set)
22. Flash key
23. Pause key
24. Redial key
25. Handfree key
26. Indicator(Charging/Incoming Calls)
27. Phone Cord Jack
28. Numeric keypad
29. Ringtones Volume
30. Direct Current Input Jack
31. Landline Jack
32. Extension Cord Jack

USB Charger

**USB Power Cable DC4.0**

Battery

Phone Line

Coiled Phone Cord

USB Data Cable

Earphone

- Phone Handset
- Coiled Phone Cord
- Dock Phone
- USB Power Cable DC4.0

- USB Data Cable
- Tablet
- USB Charger

- Phone Cord
- Battery
- Earphone

Assembling Your TELPAD

Please refer to the figure:
Insert the tablet into dock, making sure the interfaces on the tablet and the phone set are properly aligned.

Connecting and Charging

Connecting the phone
1.Connect the DC power adapter and DC power adapter line.
2.Insert the power adapter line into the dock's power line jack.
3.Insert the DC power adapter into the power source/outlet.
4.Insert the phone line into the phone line jack and the unit's phone line socket.

Connecting the Extensions

Connect the extension phone cord with the phone set into the extension cord jack.

Charging the Tablet Using the Dock

Connect the phone set to a power source. The Tablet will automatically charge once it is placed on the dock.

USB charger

DC power adapter   telephone jack

PLDT

Charging the Tablet via a Personal Computer

Using the USB Cord, insert the smaller connecting head to the tablet and insert the other connecting head to the USB port of your personal computer/laptop. The tablet will automatically charge once it is connected.

Using the Physical Keys

Power button
Volume up
Volume down

Power Button
※ Press and hold power button to:
    1. restart; 2. shutdown; 3. enter airplane mode;
    4. enter silent mode; 5. enter vibrate mode; 6. enter ringtone
※ Press shortly to lock/unlock the screen.

Volume Up/Down
※ When the Tablet is ringing, press any of the volume buttons if you want to mute the ringer.
※ On the Home screen, press to increase or decrease the ringtone volume, or set the Tablet to silent mode.
※ When using other applications, press to control the volume of music, spoken directions, and other audio sounds.
※ Press and hold to immediately adjust the ringtone volume to the maximum or minimum.

Working the Touchscreen Keys

Back
Touch to return to the previous screen.
Touch to exit from the running application.
If the on-screen keyboard is open, touch to close the keyboard.

Home
Touch to open the Home screen. It will bring you to the first panel of the Home screen.

Increase sound
Press to increase sound

Decrease sound
Press to decrease sound

Navigation
Touch to open a list of thumbnail images displaying recently operated apps.
Touch the thumbnail image of the app to open it.
Touch and hold and flick off upward or downward to remove the app from the list.

Using the Touch Screen

Touch

   By touching an item, you can select the item or launch it. For example:
   ※Touch the on-screen keyboard to insert text and/or characters.
   ※Touch an application icon to launch it.

Touch and Hold

   Touching and holding items will activate them. For example:
   ※Touch and hold an application/widget to move it.
   ※Touch and hold on a field and a menu with options will pop up.

Drag

   Touch and hold an item, move your finger on the screen to the target position.
   ※Dragging a shortcut icon to the trash will delete it.

Flick, Slide, Swipe

   Change screens by flicking, sliding, and swiping your finger on the screen. For example:
   ※Slide your finger to unlock the screen.
   ※Flick and/or swipe your finger to scroll the screen or menu, to move from screen to screen, or to view next object in the gallery.

Pinch

   Using two fingers (like your thumb and index finger), pinching inward will cause the screen to zoom out; pinching outward will cause the screen to zoom in. For example:
   ※Pinch outward to see zoomed in details of a photo in Gallery.
   ※Pinch inward to zoom out and see the whole page of a browser.

MOBILE TELPAD 7

- 3C
  - * Connect Home: 3G / PSTN / VOIP.
  - * Control Home: 3D IR Remote Controller / Smart Controller
  - * Care Home
    - ※Optional Smart Body temperature manager
    - ※Optional Smart weight scale & Body Composition manager
- GPS: GPS/A-GPS
- FM: 76-108MHZ WITH 50KHZ SETP
- Quad core 1.3Ghz
- 7" IPS 1024X600
- 8GB Flash /1GB RAM
- Rear 3MP Camera/Front 0.3MP
- Home Control
  - * Control your home theater and other devices

We can Support below Devices:

TV	MUSIC AUDIO
CABLES DSS	DVD
SAT VCR	PROJECTOR
CD RECEIVER	AIRCON

Cast Screen

The TELPAD can project its screen, displaying files to those devices which can support "Cast screen" through its "WiFi-Direct" function. Thus, the files from the MT7 can be enjoyed on a larger screen with equally superior sound quality.
Note: Wireless HDMI needed for this function is sold separately.

DLNA

Connect the TELPAD and another device (which should have DLNA function) to Wi-Fi first, launch the DLNA function for both devices, then connect them by DLNA. Video and audio will be played on the receiver device normally without noise. Meanwhile, you can proceed with other operations on the TELPAD.

If You Need More Information:
Please find User Manual in "help" under "Settings" column on the Tablet for more detailed and in-depth instructions on how to use this device, as well as answers to frequently asked questions.

How to read product Quick Guide and User Manual?

1. End users can read product Quick Guide and install device guide when they start device for the first time.
2. End users can enter "UserManualLink" in Application interface and download product User Manual according to the on-screen instruction;
3. End users can go to "Setting", select "Help" and read product User Manual and Quick Guide;

Devices Specs
TELPAD_MT7_User_Manual

Quick guide

Exclusive Apps for Your TELPAD

knAPPsack

Get a whole range of comprehensive apps and services from the PLDT knAPPsack. Click on the PLDT knAPPsack icon to get access to Telpad apps like iflix for thousands of TV series and movies, Spinnr for music streaming, and Disney for fun and exciting games.

Home Control

The TELPAD 3D IR remote control works with devices that are already in your home. It can control your TV, Cable Box, Radio, DVD player, Blu-Ray DVD Player, DVR, VCR, CD player, Audio devices, even your Aircon. It supports thousands of supported manufacturer models and is continuously growing in supported devices. You can also control your home devices through your Android mobile phone by pairing it with your TELPAD. Lastly, use the reservation mode of the TELPAD to set specific times for your home devices to automatically turn on and off. Managing your home is made easy with the PLDT HOME Telpad.

Home Care

This application allows you to monitor essential health and fitness data with the TELPAD. The monitored variables are as follows: Body weight (180kg~5kg), Body fat rate, Body water, Bone mass, Muscle mass, BMI, BMR, and Visceral fat and Body temperature.

Note: Bluetooth Body Scale and iFever Manager Dongle needed for this function is sold separately.

TELPAD MT7
Quick Guide

AURA Technology Limited
Address: RM810, Star House, 3 Salisbury Road, Tsimshatsui, Hong Kong
E-mail: Support@auratech.hk
for Android™ Android™ is a trademark of Google Inc. Use of this
trademark is subject to Google Permissions.